



---

**StrikeShield™**

---

**360° Lightning**

---

**Protection System**

- Protects Load Cells
  - Protects Instruments
  - Increases Uptime
- 

---

## **A Lightning Protection System Designed to Maximize Your Uptime**

**METTLER TOLEDO**





# Stops Lightning Damage to Load Cells and Instrumentation



**Test Report  
From Lightning  
Technologies, Inc.**


Our exclusive 360° StrikeShield™ lightning protection system consists of equipment designed specifically to prevent lightning from damaging load cells and instrumentation. It's more than just a very good warranty: it really protects.

## Less Downtime

Experienced truck scale users know that downtime can be very costly. It's not just the expense of getting a scale back up and running after a lightning strike. It's the value of the product that doesn't get weighed that can really be costly. Our 360° StrikeShield lightning protection system increases uptime.

METTLER TOLEDO load cells have been independently tested, adding to the protection system. They've passed a Lightning Test (by Lightning Technologies, Inc.) and the Robust Digital Electronic Surge Immunity Test (CSL 1027/EIC 801-S).

Your nearest METTLER TOLEDO office or authorized distributor can answer all your lightning protection questions.



	TEL	FAX		TEL	FAX	
<b>METTLER TOLEDO</b>	<b>Australia</b>	(61-3) 9644 5700	(61-3) 9645 3935	<b>Korea</b>	(82-2) 3498-3500	(82-2) 3498-3555
	<b>Austria</b>	(43-1) 604 1980	(43-1) 604 2880	<b>Malaysia</b>	(60-3) 7845 5773	(60-3) 7845-8773
	<b>Belgium</b>	(32-2) 334 0211	(32-2) 334 0334	<b>Mexico</b>	(52-5) 547 5700	(52-5) 541 2228
	<b>Brazil</b>	(55-11) 4166-7400	(55-11) 4166-7401	<b>Netherlands</b>	(31-344) 638363	(31-344) 638390
	<b>Canada</b>	(800) 638-8537	(905) 681-8036	<b>Norway</b>	(47) 22 30 44 90	(47) 22 32 70 02
	<b>China</b>	(86-519) 6642040	(86-519) 6641991	<b>Poland</b>	(48-22) 651-9232	(48-22) 651-7172
	<b>Croatia</b>	(385-1) 29 58 130	(385-1) 29 58 140	<b>Russia</b>	(7-095) 921 9211	(7-095) 921 6353
	<b>Czech Republic</b>	(420-2) 721-23150	(420-2) 721-23170	<b>Singapore</b>	(65) 6890 0011	(65) 6890 0012
	<b>Denmark</b>	(45-43) 27 08 00	(45-43) 27 08 28	<b>Slovak Republic</b>	(421-2) 4342-7496	(421-2) 4333-7190
	<b>France</b>	(33-1) 30 97 17 17	(33-1) 30 97 16 16	<b>Slovenia</b>	(386-1) 562-1801	(386-1) 562-1789
	<b>Germany</b>	(49-641) 50 70	(49-641) 52951	<b>Spain</b>	(34-93) 223-7600	(34-93) 223-0271
	<b>Hungary</b>	(36-1) 288-4040	(36-1) 288-4050	<b>Sweden</b>	(46-8) 702 50 00	(46-8) 642 45 62
	<b>India</b>	(91-22) 2857-0808	(91-22) 2857-5071	<b>Switzerland</b>	(41-1) 944 45 45	(41-1) 944 45 10
	<b>Italy</b>	(39-02) 333321	(39-02) 356-2973	<b>Taiwan</b>	(886-2) 2657-8898	(886-2) 2657-0776
	<b>Japan</b>	(81-3) 5762-0606	(81-3) 5762-0756	<b>Thailand</b>	(66-2) 723-0300	(66-2) 719-6479
	<b>Kazakhstan</b>	(7-3272) 50 63 69	(7-3272) 98 08 35	<b>United Kingdom</b>	(44-116) 235 7070	(44-116) 236 6399
<b>USA</b> 1900 Polaris Parkway Columbus, Ohio 43240 TEL. (800) 523-5123 (614) 438-4511 FAX (614) 438-4900						<b>Internet</b> www.mt.com Specifications subject to change without notice.
<b>Headquarters</b> 8606 Greifensee Switzerland TEL. (41-1) 944 22 11 FAX (41-1) 944 30 60						© 2004 Mettler-Toledo, Inc. METTLER TOLEDO® and StrikeShield™ are trademarks of Mettler-Toledo, Inc. Printed in USA.
						5M0904 TRUCK SCALES 199-TRO3191.2E

